



- ① **Istruzioni per modifica centrali TA - TE in centrali TA - TE GENERATION**
- Ⓒ *Instructions for modification from TA - TE units into TA - TE GENERATION units*
- Ⓔ *Istruzioni pour modifier les centrales TA - TE en centrales TA - TE GENERATION*
- Ⓔ *Istrucciones para modificar las centrales TA - TE en centrales TA - TE GENERATION*
- Ⓓ *Anleitung für die Umänderung von Zentralen TA - TE in Zentralen TA - TE GENERATION*

Modelli - models - modèles - modelos - Modelle :

- | | | |
|------------|-----------------|----------|
| - Mini TA | - Media Plus TA | - 100 TA |
| - Mini TE | - Media Plus TE | - 100 TE |
| - Media TA | - 50 TA | |
| - Media TE | - 50 TE | |





Smontaggio / Disassembling / Demontage / Demontaje / Abmontage




1)




2)



3)



4)



5)



6)



7)



8)



9)



10)



11)



12)



Smontaggio / Disassembling / Demontage / Demontaje / Abmontage



13)



14)



15)



16)



17)



18)



19)



20)



21)



22)



Assemblaggio / Assembling / Assemblage / Assemblaje / Assemblage



1)



2)



3)




4)



5)



6)



7)




8)



9)



10)



11)



12)



Assemblaggio / Assembling / Assemblage / Assemblaje / Assemblage



13)



14)



15)



16)



17)



18)



19)



20)



21)




22)




23)

F0920132

Assemblaggio / Assembling / Assemblage / Assemblaje / Assemblage




24)



25)



26) * Sostituire il fusibile T10A con quello da T16A presente nel kit



27)



28)



29)



30)



31)



32)



33)



34)



35)



36)



37)